



(ACFT CAT A,B,C,D)



<p>MAPt BEN DME 1.3 (BCL D1.5)</p> <p>Danger Areas Not Active: Climb straight ahead to 1700. At 1700, turn right to return to VOR BEN at 3100. Note: No turns permitted before MAPt.</p>
--



ALTERNATIVE PROCEDURE EXTENDED HOLDING PATTERN Overhead VOR DME BEN in holding pattern, turn right and descend on extended outbound leg to 2200. At BEN DME 8.5 (BCL D8.7) turn right to intercept FAT. When established, continue as for main procedure.

NOTES

- 1 FAT is offset 3.7° from RWY 24 C/L.
- 2 Procedures interact with Danger Areas EGD701A, 701B, 701C, 701Y and EGD704. Procedure available subject to ATC permission.
- 3 Unlocks of BCL DME may be observed between 070 and 080.
- 4 To commence procedure from hold, overhead VOR DME BEN, fly baseturn manoeuvre on CAT A,B R198, CAT C,D R176 for 1 MIN then turn right to return to the facility on 054° **not below 2100**.

CHANGE (11/25): MAG INFO