

Instrument Approach Procedure Coding Tables

Exeter RNP RWY 08 - Instrument Approach Procedure via SISRI

Designator	Sequence Number	Path Terminator	Waypoint Name	Fly-over	Course/Track °M (°T)	Turn Direction	Level Constraint	Speed Constraint	Co-ordinates	Remarks and Distance to MAPt
R08L	001	IF	SISRI	N	-	-	<u>3400</u>	210	504600.11N 0034503.81W	IAF
R08L	002	TF	TE08I	N	166° (165.86°)	LEFT	<u>2300</u>	-	504109.51N 0034308.54W	IF / 11.4NM
R08L	003	TF	TE08F	N	076° (075.88°)	-	2200	-	504222.36N 0033530.88W	FAF / 6.4NM
R08L	004	TF	RW08	Y	077° (075.98°)	-	-	-	504355.45N 0032540.83W	MAPt
R08L	005	CA	-	-	077° (075.98°)	-	1000	210	-	At 1000' revert to conventional navigation

Exeter RNP RWY 08 - Instrument Approach Procedure via EBOBA

Designator	Sequence Number	Path Terminator	Waypoint Name	Fly-over	Course/Track °M (°T)	Turn Direction	Level Constraint	Speed Constraint	Co-ordinates	Remarks and Distance to MAPt
R08C	001	IF	EBOBA	N	-	-	<u>3400</u>	210	504025.56N 0034742.94W	IAF
R08C	002	TF	TE08I	N	076° (075.82°)	-	<u>2300</u>	-	504109.51N 0034308.54W	IF / 11.4NM
R08C	003	TF	TE08F	N	076° (075.88°)	-	2200	-	504222.36N 0033530.88W	FAF / 6.4NM
R08C	004	TF	RW08	Y	077° (075.98°)	-	-	-	504355.45N 0032540.83W	MAPt
R08C	005	CA	-	-	077° (075.98°)	-	1000	210	-	At 1000' revert to conventional navigation

Exeter RNP RWY 08 - Instrument Approach Procedure via OTBOT

Designator	Sequence Number	Path Terminator	Waypoint Name	Fly-over	Course/Track °M (°T)	Turn Direction	Level Constraint	Speed Constraint	Co-ordinates	Remarks and Distance to MAPt
R08R	001	IF	OTBOT	N	-	-	<u>3400</u>	210	503618.88N 0034113.66W	IAF
R08R	002	TF	TE08I	N	346° (345.90°)	RIGHT	<u>2300</u>	-	504109.51N 0034308.54W	IF / 11.4NM
R08R	003	TF	TE08F	N	076° (075.88°)	-	2200	-	504222.36N 0033530.88W	FAF / 6.4NM
R08R	004	TF	RW08	Y	077° (075.98°)	-	-	-	504355.45N 0032540.83W	MAPt
R08R	005	CA	-	-	077° (075.98°)	-	1000	210	-	At 1000' revert to conventional navigation